## PRECAUTIONS FOR THE PROPER USE OF CONDENSATE DRAINS

All condensate drains are fully warranteed for material and workmanship. Each unit is fully tested prior to leaving our plant. In the event you find that this unit does not perform satisfactorily after installation, it should be returned prepaid to our factory. A credit or replacement can only be issued after our technicians inspect the unit to determine cause of complaint. The warranty will be void if it is determined the unit was damaged due to improper installation, physical damage or alteration.

**CAUTION**: Do not remove enclosure covers or tamper with any components. Over a fourhour period your refrigerator will dump a quantity of defrost water. The dump should not exceed the evaporator capacity. The following listing serves as a guide to determine the proper model for your specific installation:

Part No	. Voltage	Evaporation	Capacity	Watts	Size	Body
		Rate			In Inches	Туре
30-OS	220	8 Oz/Hr	38 Oz.	160	10 x 4 x 2 7/8	Cast Aluminum
31	220	6 Oz/Hr	50 Oz.	160	10 x 4 1/2 x 3 3/8	Cast Aluminum
75	220	14 Oz/Hr	75 Oz.	320	10 x 9 x 2 3/4	Cast Aluminum

Use a seperate electrical line connected to a fuse block or circuit breaker of proper capacity. Voltage drops will decrease operating efficiency and voltage surges will damage heating elements. Each unit is stamped with voltage rating.

All units must be grounded.

All units should be installed in adequately ventilated compartments to allow moisture laden air to be carried off.

DO NOT REST UNITS ON WOOD SURFACE OR NEAR ANY FLAMMABLE MATERIAL. ENCLOSED SPRINGS SHOULD BE INSTALLED AS LEGS.

Do not allow units to lie on wet surfaces. Clean pan regularly for maximum efficiency.

The condensate evaporator drain should be electrically installed with a pull out type plug so that it can be easily removed from the compressor compartment for cleaning.





SEALED UNIT PARTS CO., INC. P.O. Box 21 • 2230 Landmark Place • Allenwood, NJ 08720 USA Phone: 732-223-6644 Fax: 732-223-1617